


chyrp



USER MANUAL

PRODUCT FEATURES

- Wireless functionality with a range of 33 ft (10 m)
- Compatible with smartphones and other media devices
- Built-in rechargeable battery
- Comes with an adjustable carrying strap

FUNCTIONS

1. Power on/off/play/pause button
2. Micro USB Charging port

Press and hold the multi-function button (1) for 4 seconds to power Chyrp on or off.

Press the multi-function button (1) once to play music. Press once again to pause music.

WIRELESS CONNECTION

When Chyrp is turned on, it will be automatically discoverable by your wireless devices. Select “Chyrp” from your list of devices. Chyrp will indicate a successful wireless pairing by changing from a flashing white LED light to a solid white LED light. Once your device is connected, Chyrp will pair automatically upon future use and stay paired until you manually disconnect it.

Chyrp will automatically power off within 15 minutes if no devices are paired.

CHARGING

When Chyrp is low on power, connect the micro-USB port with the charging cable and its USB plug into a USB port with power on the other end. While charging, the LED shows red and will turn off after the battery is fully charged.

SPECIFICATIONS

- Wireless Range: 33 ft (10 m)
- Wireless Connection: V5.0
- Audio Playback Time: 1 hour @ 100% Volume
- Frequency Response(0db @1khz): 100Hz-20KHz
- Speaker Drivers: 36mm
- Amplifier Max Output: 2W
- Battery: 3.7V 300mAh
- Battery Charge Time: 1 hour and 30 minutes
- Battery Charge Voltage: DC5V/1A
- Battery Charge Current: 300-500mAh
- Accessories: Micro USB Cable & User Manual

See more at:
www.origaudiopromo.com

Origaudio™

© 2020 Forty Four Group, LLC., d/b/a Origaudio
Printed in California · Made in China

