


# DRIPZ

## USER MANUAL



### PRODUCT FEATURES

- IPX7 waterproof rating
- Up to 5 hours of audio playtime
- Built-in microphone
- Wireless functionality with a range of 33 ft (10 m)
- Compatible with smartphones and other media devices
- Built-in rechargeable battery
- Comes with a magnetic closure carrying case

### CHARGING THE DEDICATED CARRYING CASE

*Note: Before charging your Dripz earbuds for the first time, please remove and discard the plastic film from the back of each earbud.*

Connect the provided USB charging cable to a power source and insert the USB-C tip into the charging port located on the back of the carrying case. Indicator lights on the front of the case will light up and blink when Dripz are charging. The Dripz are at full battery capacity once all four (4) lights are lit up. Let the Dripz reach full charge before use. This will take approximately 1.5 hours if the battery was completely drained.

### PAIRING YOUR EARBUDS

**How to pair both of your Dripz earbuds at once:** Once the Dripz earbuds are fully charged, remove the earbuds from their charging case. The LED light on one earbud will flash white and

the other will be solid white. Turn on the wireless pairing settings on your smartphone, tablet, or computer and select the device labeled “Dripz”. Once Dripz earbuds are paired, the LED light on both earbuds will be solid white. Once your device is connected, the earbuds will pair automatically upon future use and stay paired until you manually disconnect it.

If the earbuds are turned off, press and hold the multi-function buttons for 2 seconds until you see the LED light turns on.

**How to pair just one single earbud:** Remove one Dripz earbud from the charging case. Wait for the LED light on that earbud to flash white and then connect to your device’s wireless pairing settings as described earlier.

### HOW TO RESET THE EARBUDS

Press and hold the multi-function buttons for 8 seconds until the Dripz earbuds turn on.

## FUNCTIONS

<b>Turn On</b>	Remove Dripz earbuds from the charging case and the earbuds will turn on automatically. Press and hold the multi-function buttons on both earbuds for 3 seconds to turn Dripz earbuds on manually.
<b>Turn Off</b>	Place earbuds back inside the charging case and the earbuds will turn off automatically. Press and hold the multi-function buttons on both earbuds for 3 seconds to turn Dripz earbuds off manually.
<b>Play/Pause</b>	Click the multi-function button on either earbud once to pause or play Dripz.
<b>Previous/Next</b>	Hold the multi-function button on the Right earbud for 1.5 seconds to skip a song. Hold the multi-function button on the Left earbud for 1.5 seconds to go back to a previous song.
<b>Volume Up/Down</b>	Double-click the multi-function button on the Right earbud to turn the volume up. Double-click the multi-function button on the Left earbud to turn the volume down.
<b>Answer/End Call</b>	Click the multi-function button on either earbud once when receiving incoming calls to accept calls. Click the multi-function button on either earbud once during the phone call to end the call.
<b>Reject Call</b>	Press and hold the multi-function button for 2 seconds to reject incoming calls.
<b>Activate Voice Assistant</b>	Triple-click the multi-function button on either earbud to activate your device's voice assistant.

## SPECIFICATIONS

- Earbud playback time: 5 hours
- Earbud charging time: 1.5 hours
- Carrying case charging time: 2.5 hours
- Earbud battery: 3.7V/50mAh
- Charging case battery: 3.7V/800mAh
- Accessories included: USB-C charging cable & three (3) silicone ear tips (sizes Small / Medium / Large)

See more at:  
[www.origaudiopromo.com](http://www.origaudiopromo.com)

*Origaudio*<sup>™</sup>

© 2020 Forty Four Group, LLC., d/b/a Origaudio  
Printed in California · Made in China

