


Inflatable Loveseat

Product Parts

- 1 - Inflatable Loveseat
- 2 - Graphic
- 3 - Electric Blower (optional)
- 4 - Hand Pump (optional)




Display Set-Up

Step 1

Begin by removing all parts and placing them on a clean, flat surface. Ensure you have all the components listed above.

Step 2


Insert the deflated Inflatable Loveseat (1) into the Graphic (2) and Insert the Optional Blower or Pump's (3/4) hose into the intake valve of the Inflatable Loveseat (1) and begin to inflate until Loveseat (1) is about 75% full.



Step 3

Adjust the seams of the Graphic (2) to align to the seams of the Inflatable Loveseat (1). Once aligned, continue to inflate until Graphic (2) is tight to the Inflatable Loveseat (1).

*** DO NOT OVER INFLATE THE LOVESEAT AS THIS MAY CAUSE DAMAGE.**



Step 4

Close the Intake Valve on the Inflatable Loveseat (1).

