



Inflatable Ottoman

Product Parts


- 1 - Inflatable Ottoman
- 2 - Graphic
- 3 - Electric Blower (optional)
- 4 - Hand Pump (optional)



Display Set-Up


Step 1

With the opening of the Graphic (2) facing you, insert the deflated Inflatable Ottoman (1) into the Graphic (2) by keeping the air intake valve toward the bottom opening of the Graphic (2).



Step 3

Close the Intake Valve on the Inflatable Ottoman (1).



Step 2

Insert the Optional Blower or Pump's (3/4) hose into the intake valve of the Inflatable Chair (1) and begin to inflate until about 2/3 full. *** DO NOT FULLY INFLATE AT THIS TIME.**

Adjust the seams of the Graphic (2) to align to the seams of the Inflatable Ottoman (1). Once aligned, begin to inflate until graphic is tight to the Inflatable Ottoman (1).

*** DO NOT OVER INFLATE THE OTTOMAN AS THIS MAY CAUSE DAMAGE.**

