


Product Parts

- 1 - Banner Rod (x4)
- 2 - Backpack
- 3 - Graphic



Set-up Instructions

Step 1

Remove all of the parts from package and set them, along with your graphic, on a flat, clean surface.

Step 3

Insert the base of the rods into the opposing corner slots on the back of the backpack.




Step 5

Secure Backpack to your person.

Step 2

Unfold the four shock-corded Banner Rods (a,b,c and d) and insert the ends together to make four long rods.



Step 4

Insert the hooks of the rods into the grommets on the four corners of the banner.



Storage & Care

Place all poles into the zippered section of the backpack and place the rolled graphic into the outside pouch into the backpack. Clean backpack with damp cloth and wipe dry. Spot Clean graphics with dry cloth.