

PRODUCT SPECIFICATIONS/EARBUDS:

Playtime: Up to 3 hours
(on a fully charged battery)

Wireless Range: up to 33 feet

Microphone sensitivity: -40±2db

Wireless Frequency Band: 2.4-2.48Ghz

Battery: Button cell 55mAh

Working Voltage: 3.2V-4.2V

Wireless Range: 33 feet

Charging Time: Approximately 2 hours

PRODUCT SPECIFICATIONS/CHARGING BASE AND POWER BANK:

Capacity: 4400mAh

DC Output Voltage: DC5V


DC Output Current (Max): 1A

DC Charging Voltage: DC5V

DC Charging Current (Max): 1A

WARRANTY INFORMATION:

Origaudio warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of six (6) months from the date of original purchase.



USER MANUAL True Wireless Earbuds + All-In-One Solution

Origaudio™

INTRODUCTION


Your new Pionears True Wireless earbuds are designed to link with your wireless smartphone or device and allow you to listen to music and answer phone calls. Please review this manual carefully to make sure you are getting the maximum benefit from all of the features of your new Pionears.

SAFETY POINTERS:

- Listening to music at very high levels for extended periods is great for ignoring people. It's even better at causing hearing loss. Don't go deaf. Adjust volume before inserting the buds into your ears.
- Do not disassemble, modify or alter this product in any way. Doing so may cause undesired effects such as electric shocks, product malfunction, fire hazards, or alien abduction. Not to mention, it'll void your product warranty.
- Be practical when using your awesome new Pionears. Don't wear them in situations that require the full attention of your hearing. For example: driving, crossing busy intersections, when your doctor gives you your test results, and never ever during boring work meetings (wink).

WHAT'S INCLUDED:

- [A] Pair of Pionears Earbuds
- [B] 4400mAh earbud charging base/power bank
- [C] USB charging cable
- [D] 3 pairs of silicon ear cushions in large, medium and small
- [E] Wall charging dock



CHARGING YOUR EARBUDS AND BASE/ POWER BANK:

- Fully charge your Pioneers and charging base by housing the earbuds in the base and using one of these two methods:
(A) Place the base into the charging dock while plugged into an AC power source (110-240V). Make sure that when sitting on the dock, the logo plate faces outward.
(B) Connect the provided USB charging cable to the base and plug it into your computer or USB wall adaptor.
- During the charging process, the blue indicator lights on the side of the charging base will light up and blink blue. When the base is fully charged, all 4 indicator lights will show solid blue lights.
- When the earbuds are charging in the base, their indicators lights will appear red. Once the earbuds are fully charged, the indicator lights will turn off completely.

CHARGING YOUR DEVICE WITH THE POWER BANK:

Connect your USB device cord to the USB port found on the bottom of the power bank unit. Press the power button on the back bottom corner of the power bank to start the charging process. And don't worry about battery drainage. If the power button is accidentally pressed and no device is connected via the USB port, the power bank automatically shuts itself off after one minute of inactivity/standby status.

EARBUDS POWER ON/OFF:

To turn on, press and hold the multifunction button for approximately 4 seconds until they flash blue. To turn off, press and hold the multifunction button for approximately 4 seconds until they flash red.

PLAY MUSIC:

To pause your music press the MFB once while music is playing. To play your music press the MFB once to resume your music.

CALLING:

Answer/End incoming call > Press MFB once.

Redial last call > Press MFB twice.

NOTE: When using the call feature to speak or listen, the microphone is found in only one of the two earbuds. The second earbud will not transmit any sound during calls when the microphone is in use. While the call is in progress, the music will pause and once the call has ended, the music play will be automatically resumed.

PAIRING YOUR EARBUDS:

1. Press and hold the multi function button (MFB) on the top of the BOTH earbuds for approximately 7 seconds. Make sure earbuds are within 12 inches of each other during this pairing process. (They have abandonment issues.)
2. During the 7 seconds you will notice the indicator lights on both buds flash blue once, turn off, followed by quick alternating flashing red and blue lights. Once both buds flash the alternating red and blue lights, you may release the multifunction buttons. The alternating red/blue lights on both earbuds indicate the earbuds are pairing to each other.

3. Once the earbuds finish pairing to one another, one will flash alternating blue and red light, while the other will blink blue. This indicates the earbuds are ready to be paired to your wireless device. On your list of wireless devices, select and pair the item listed as "Pioneers." After being successfully paired to your device, the earbuds will show a slow blinking blue indicator light.
4. NOTE: Earbuds must be paired to each other FIRST before they can pair with your wireless device. If you see two "Pioneers" listed in your device list, please turn off your earbuds and restart the process.
5. For a step-by-step instruction video on pairing your Pioneers to your device, visit: <http://bit.ly/pioneerspair>

Origaudio[™]