

# BOLTRON

## WIRELESS CHARGING PAD

*Please read the operating instructions thoroughly to guarantee proper use of your Boltron.*

*NOTE: Smartphone must already have a wireless charging receiver installed and wireless charging enabled to wirelessly charge. Do not charge smartwatches with this device.*

### **HOW TO CHARGE**

Plug the Boltron into a power source using the provided AC adapter cord. The Boltron's indicator lights will glow green underneath all three wireless stations indicating it is in standby mode and ready to charge. Place up to 3 wireless charging-compatible devices on the marked crosses (+). You may need to adjust placement until the indicator light turns blue signaling the device is successfully charging.

There are also 2 standard USB ports that can be used to directly plug and charge 2 more devices simultaneously.

## **APPLICATION OF THE NON-SLIP PAD:**

Three (3) non-slip pads are provided in the Boltron packaging. These pads can be applied on the printed surface within the indented cross (+) area. These pads are intended to help your device stay on the Boltron during wireless charging but is not necessary for device usage.

## **SAFETY POINTERS**

- Do NOT use the Boltron to wirelessly charge smartwatches. This device is designed to charge smartphones only.
- It's recommended to keep a minimum distance of 6 inches between the Boltron and any implanted medical device.
- Keep the Boltron dry, and do not store or use in an extreme hot or cold environment.
- Do not take the Boltron apart.
- In case of abnormal behavior, discontinue use.

## **SPECIFICATIONS**

Input: 12V/3A 36W

Wired Output: USB 2.0 - 5V / 2.1A (Max)

Wireless Output: 5V / 1.5A

Frequency: 110 - 205kHz

Size: 10.9" x 3.1" x 0.5"