

Display Set-Up

Step 1

Remove the parts from the bag and place on a clean, flat surface, along with your banner. Lay the Left Frame Assembly (1) on its side and unfold. First, open the levers on each of the two poles. Push the poles down into the joints as shown. Repeat step for Right Frame Assembly (2).



Step 3

Insert Top Horizontal Pole (3) into the Left Frame Assembly (1) by matching up the labels on the hardware. Push in the pushbutton and insert as shown. Repeat step for Bottom Pole (4).



Step 5

Connect the Right Frame Assembly (2) to the Top Horizontal Pole (3) as shown. Repeat step for Bottom Horizontal Pole (4).



Step 2

Stand the Left Frame Assembly (1) upright and fold open and push the Vertical poles down into the joints as shown. Repeat step for Right Frame Assembly (2).



Step 4

Slide the Graphic (5) on the Top and Bottom Horizontal Poles (3 & 4) as shown. Continue to slide the graphic until the Horizontal Poles are exposed on the opposite end.



Step 6

To adjust the height, open the telescoping clamp as shown.



Display Set-Up Continued...


Step 7

Center the Graphic on the unit and with two people, begin to raise the top vertical poles upward until the graphic is taught to the frame as shown.

* Verticle poles are not meant to exceed product height of 94.125"

Step 8

Snap the telescoping clamps closed to secure poles.



To adjust the width, locate the Blue "A" and "B" Labels on the Left Frame Assembly (1). Push in the push-button and slide pole to desired setting.

- "A" Setting for the 10' Bravo Graphic (Do Not exceed 10' width setting)
- "B" Setting for the 8' Bravo Graphic (Frame will go narrower than this setting without the use of the push-button)





Storage & Care

Place all product parts into Carry Case (6) and store in a cool dry location.



Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.